

# CSE 3461: Taming troll

Instructor: Adam C. Champion

The advice below on troll comes from previous CSE 3461 students. Labs 3 and 4 are more difficult than Labs 1 and 2 as three or four processes communicate with each other: the client, the server, and one or two trolls. **Do not procrastinate**; Lab 4 builds on Lab 3.

## Thoughts on Troll

There has been confusion about how to use troll. This section is to provide insight into troll's behavior and usage and hopefully clarify numerous questions.

### UDP 101

In UDP network programming, you send datagrams from a source host to a destination host. Here, I'll use several terms; be sure to get them straightened out:

#### Datagram:

Another name for a packet sent using UDP (the data you pass to Python's `sendto()` method)

#### Client machine:

The machine executing `ftpc.py`. The lab document uses `beta.cse.ohio-state.edu`.

`client_ip:`

The IP address of the client machine

`client_port:`

The port used by `ftpc.py` to send datagrams.<sup>1</sup> You can pick this.

#### Server machine:

The machine executing `ftps.py`. The lab document uses `gamma.cse.ohio-state.edu`.

`server_ip:`

The IP address of the server machine

`server_port:`

The port used by `ftps.py` to receive incoming datagrams. You can pick this.

#### troll machine:

The machine executing troll. The lab document uses `beta.cse.ohio-state.edu`.<sup>2</sup>

`troll_ip:`

troll's IP address.<sup>3</sup>

`troll_port:`

The port used by the troll program. You can pick this.<sup>3</sup>

---

<sup>1</sup>In typical UDP programming, you don't specify a port on the client side; it's sufficient to call `sendto()` without `bind()`. In this case, the OS will pick any available port for you to use. However, troll only accepts packets from a specified port, so we have to manually tell the OS which port to use by `bind()`ing the socket to `client_ip` and `client_port`.

<sup>2</sup>The lab document demonstrates using the program by running troll and `ftpc.py` on the same machine (`beta.cse.ohio-state.edu`). This is not strictly necessary: troll could run on a third host if we wanted.

<sup>3</sup>There are a lot of IPs and ports floating around. It's helpful to pair them up and associate them in your head with one of the three programs being used in this lab. For example, the server has `server_ip` and listens on `server_port`. troll lives on `troll_ip` and listens on `troll_port`. Don't worry if `troll_ip` is the same as `client_ip`, because you can just pick different ports for them to use. These values are specified in pairs so frequently that a popular shorthand is to simply concatenate them with a ":". For example, the troll machine is `client_ip:client_port`.

## Troll

troll is a network program with pretty simple behavior.<sup>4</sup> It listens for datagrams coming in on troll\_port and forwards them somewhere else. More specifically, it will only accept datagrams from a single IP/port combination, and it will only send them to a single IP/port combination.

Let's define some more terms:

source\_ip:

The IP from which troll will accept datagrams

source\_port:

The port from which troll will accept datagrams

dest\_ip:

The IP to which troll will forward datagrams

dest\_port:

The port to which troll will forward datagrams

troll's usage looks like this (on one line):<sup>5</sup>

```
[me@beta ~/Lab3]$ ./troll -C source_ip -a source\_port -S dest_ip  
-b dest_port -r -t -x 0 -s 1
```

## Troll Use in Lab 3

Your first priority for Lab 3 should be to get the transfer process to work using datagrams (UDP) instead of a TCP stream. If this doesn't work, you might as well forget about using troll.

Then, you should make a small modification that allows the client port to be specified on the command line (footnote 1).

In this section, I'm going to assume that your implementation works like this:

```
# Start the server on gamma, binding to server_ip:server_port  
[me@gamma Lab3]\$ python3 ftps.py server_port  
  
# Start the client on beta, sending datagrams to server_ip:server_port  
# bound client_address:client_port (ON ONE LINE)  
[me@beta Lab3]\$ python3 ftpc.py server_ip server_port client_ip client_port  
../image1.jpg
```

This should look almost exactly like Lab 2 with one exception: you are required to specify client\_ip and client\_port when executing ftpc.py.

To properly implement this lab, you need to be able to route your file transfer through troll. This is deceptively simple! troll should be configured to **accept** packets from the **source** client\_ip:client\_port and send these packets to the **destination** server\_ip:server\_port (if you're confused about how to configure troll for a specific source and destination, then re-read the previous section).

---

<sup>4</sup>It's not actually this simple ... It can be configured to "troll" you by randomly dropping or rearranging packets. Lol.

<sup>5</sup>Using the -s 1 option decreases the troll delay from 10 ms to 1 ms, which should literally save you an order of magnitude of time when transferring large files.

Then, instead of directing the client program `ftpc.py` to send datagrams to `server_ip:server_port`, you should direct the client to send to `troll_ip:troll_port`.

If all goes well (and your `ftps.py/ftpc.py` worked without `troll`), your server should receive datagrams from `troll`.

## Running troll

Some students have had trouble getting `troll` to run. When I taught CSE 3461 in Summer 2015, my students found that if you run

```
sock.sendto(data,('',port))
```

on the client, then you must run `troll` as follows (on one line):

```
troll -C 127.0.0.1 -S <IP-address-of-gamma> -a <client-port-on-beta>
-b <server-port-on-gamma> -r -t -x 0 <troll-port-on-beta>
```

But if you run

```
ip = socket.gethostbyname(socket.gethostname())
sock.sendto(data, (ip, port))
```

on the client, then you must run (on one line):

```
troll -C <IP-address-of-beta> -S <IP-address-of-gamma>
-a <client-port-on-beta> -b <server-port-on-gamma> -r -t -x 0
<troll-port-on-beta>
```

If you hard-code the client port using `bind()`, you need to run `troll` as follows (on one line):

```
troll -C <IP-address-of-beta OR 127.0.0.1> -S <IP-address-of-gamma>
-a <VALUE_YOU_HARDCODED> -b <server-port-on-gamma> -r -t -x 0
<troll-port-on-beta>
```

In all cases, **please document how to run the lab in the README file** so the graders can run your lab!